

Cut-Away View Floor Leveling Plan Back Bathroom

Screw Lengths As Necessary To Screw New Plywood Through Leveling Compounds and Into Existing, But Not Joists

